

← Ubuntu - Install Ubuntu On Your System76 Computer

edit on qithub

System76 computers use a standard Ubuntu installation disc and the System76 Driver to fully restore the system to factory settings.

Oryx Pro (oryp2) Touchpad

On our second generation Oryx Pro (oryp2), the System76 driver is required for the touchpad. Please use the keyboard or an external mouse for the initial install steps and until the driver is installed.

Recent Upgrade

If your recently upgraded system does not boot, it can often be recovered. If you see a flashing underscore on the screen after booting, then it's likely that Ubuntu's bootloader (GRUB) was not properly updated. To restore it, see How to Restore Grub Boot-loader

Create Install Media

First, you'll need to create bootable media you can restore or install Ubuntu with.

Create an Installation USB	Create an Installation DVD
Using Ubuntu	Using Ubuntu
Using Windows	Using Windows
Using Mac OS X	Using Mac OS X


Boot From Install Media

Once you have the disk made, reboot your system. You'll need to tell the computer to boot from the Live Disk. Immediately after you turn the computer on:




NVIDIA Graphics

Ubuntu may need a special option enabled to install and boot from Ubuntu until the NVIDIA driver can be installed as described below. If the installer doesn't show an image after this screen, please follow the next instructions:



When you see the above screen, press any key to enter the initial configuration screen. Now, push 6 to choose additional options. Move the box down to **nomodeset**, press Enter to select it, then 5 to go back to the installer choices. Pick either **Try Ubuntu** or **Install Ubuntu** as described next.



Once Ubuntu starts, you will be asked to **Try Ubuntu** or to **Install Ubuntu**. If you are attempting to restore a broken operating system, please choose **Try Ubuntu**. First, we recommend backing up all important files from your computer. The restore process can leave your files intact, but it's best to be safe in case something goes wrong. Next, double-click on the **Install Ubuntu** icon on the desktop.

If all of your files are backed up, or if you are installing from scratch, you'll need to pick the **Install Ubuntu** option to continue with the installation. Please check the box labeled **Download updates while installing Ubuntu** to ensure that your new installation is fully up to date once the installation is complete.



Install Ubuntu

Ubuntu will present several options when installing:

🙉 Install (as superuser)
Installation type
This computer currently has Ubuntu Yakkety Yak on it. What would you like to do?
 Upgrade Ubuntu Yakkety Yak to Ubuntu 16.10 Documents, music, and other personal files will be kept. Installed software will be kept where possible. System-wide settings will be cleared.
Erase Ubuntu Yakkety Yak and reinstall Warning: This will delete all your Ubuntu Yakkety Yak programs, documents, photos, music, and any other files.
 Install Ubuntu 16.10 alongside Ubuntu Yakkety Yak Documents, music, and other personal files will be kept. You can choose which operating system you want each time the computer starts up.
 Erase disk and install Ubuntu Warning: This will delete all your programs, documents, photos, music, and any other files in all operating systems.
 Encrypt the new Ubuntu installation for security You will choose a security key in the next step.
Use LVM with the new Ubuntu installation This will set up Logical Volume Management. It allows taking snapshots and easier partition resizing.
O Something else You can create or resize partitions yourself, or choose multiple partitions for Ubuntu.
Quit Back Install Now

Option	Action
Upgrade	To preserve everything in the

Install System76 Driver

Once you've reinstalled Ubuntu, you'll need to download and install the <u>System76 Driver</u>. Open the <u>Terminal</u> (search <u>Terminal</u> from the Ubuntu (4) dash or press Ctrl + Alt + 1, then enter the following commands:

sudo apt-add-repository -y ppa:system76-dev/stable sudo apt update sudo apt install system76-driver

NVIDIA Graphics

If you ordered a system with a discrete NVIDIA graphics card, you will need to manually install the drivers for your card to get the optimum performance. Please run the following command after the above commands to install the driver:

sudo apt install system76-driver-nvidia

If 'nomodeset' Was Used

The nomodeset modifier needs to be removed after installing the NVIDIA driver. Please run this command to edit the startup options file:

sudo gedit /etc/default/grub

Update this line:

GRUB_CMDLINE_LINUX="nomodeset"

to:

GRUB_CMDLINE_LINUX=""

Then save the file, exit the editor, and run this command to make the change permanent:

sudo update-grub

Once the process is finished, restart your computer for all changes to take effect.

